

SAFETY INSTRUCTIONS

- » *Installation, commissioning and maintenance shall only be carried out by qualified persons.*
- » *Work on the electrical connections may only be carried out by persons who are qualified and authorized for these activities.*
- » *Do not activate the power supply until the installation is completed.*
- » *The power supply must be disconnected during maintenance work.*
- » *Warning! No external loads may act on the devices.*



DESCRIPTION

This valve supervisory switch is designed to work with Apollo-loop protocol compatible fire panels.

Supported communication protocols are XP95/Discovery and CoreProtocol.

UW3 switches work with magnet sensing technology and hence require the provided magnet placed at the marked housing location to be in their normal state. Removing the magnet will trigger an alarm. Furthermore, opening the housing will also trigger an alarm (tamper resistance).

Notice:

This switch is certified as Enhanced Security by FM Approvals according to standard 3135, i.e. the valve inspection interval is extended from weekly to semiannually.

Download product files:
www.mecon.de/downloads/



LEGAL NOTICE

All rights reserved. Any reproduction of this documentation, even in part and regardless of the method used, is prohibited without the prior written consent of MECON GmbH. Subject to change without notice. Copyright 2025 by MECON GmbH

MECON
SAFETY CONTROL

MECON GmbH
Roentgenstrasse 105
50169 Kerpen
Germany

Phone: +49 (0) 2237 600 06 - 0

Mail: info@mecon.de
Web: www.mecon.de

MECON
SAFETY CONTROL

UW30-AE5A#

INSTALLATION INSTRUCTIONS Addressable Supervisory Switch With Enhanced Security Apollo



www.mecon.de
UW30-AE5A# / 25-04

SPECIFICATIONS

Min. & Max. working voltages	18 ... 30 V DC
Max. switching current rating	200 mA
Housing material	Polysterol
Cable cross section	0.34 ... 1.5 mm ² (22 ... 15 AWG)
Dimensions (L x W x H)	100 x 50 x 40 mm
Protection class	IP65

ELECTRICAL INSTALLATION

Wire the SLC loop of your Fire alarm control panel (FACP) to the UW3 as shown in figure 1 by the following steps:

1. Attach the L1 (-) contact ① of your FACP to terminal 2 ⑤ of the Apollo module ③.
2. Attach the L2 (+) contact ② of your FACP to terminal 1 ④ of the Apollo module ③.

To attach further UW3 A E5 A devices to the same SLC loop, daisy chain them as shown:

3. Attach the next UW3 devices terminal 1 with the L2 (+) contact ⑦ to terminal 1 ④ of the current device.
4. Attach terminal 2 of the next UW3 device with the L1 (-) contact ⑧ to terminal 3 ⑥ of the current device.

EXAMPLE WIRING CONFIGURATION




Fig. 1: Example wiring configuration